

**wheel
breakdown**



eBeam®



eBeam

wheel breakdown

Interactive Wheels



Desktop Wheel

This is the primary eBeam wheel displayed when you first launch eBeam Interact. You can use it to launch tools and applications. Open the Scrapbook, launch Powerpoint and quickly calibrate!



Scrapbook Wheel

This is the eBeam wheel displayed when using Scrapbook. It gives you the tools to annotate and perform interactive activities easily. Plus this wheel is customizable.



Annotation Wheel

This is the wheel used in annotation mode. Even outside the scrapbook you can quickly make a note, correction, hold an impromptu meeting and one button save.



PowerPoint Wheel


This is the wheel displayed when in presentation mode in Microsoft PowerPoint. This unique palette will help you navigate slide to slide, quickly make notes, or highlight, while having the added power of not saving as you go!



wheel breakdown

Desktop Wheel

Primary menu



Secondary menus







wheel breakdown

Scrapbook Wheel

Primary menu



Secondary menus





wheel breakdown

Annotation Wheel

Primary menu

Click for Digital Highlighter
(wheel will change and allow color and line font to be changed)

Click for Digital Marker
(wheel will change and allow color and line font to be changed)

Click for Shapes and Design Templates

Click to Redo

Click to Undo

Click to Save Annotations
(saved to scrapbook automatically)

Click for Digital Eraser
(wheel will change and allow size or eraser to be changed)

Click for Pointer
(change from marker, highlighter or etc. back to pointer in instant)

Secondary menus

Record video/audio

Select pen/highlighter color and line thickness





wheel breakdown

PowerPoint Wheel

Primary menu

Click for Digital Highlighter
(wheel will change and allow color and line font to be changed)

Click to go back in Presentation

Click to Exit Presentation

Click for Digital Marker
(wheel will change and allow color and line font to be changed)

Click for Shapes and Design Templates

Click to Move Forward in Presentation
(or touch stylus to surface)

Click for Digital Eraser
(wheel will change and allow size or eraser to be changed)

Click for Pointer
(change from marker, highlighter or etc. back to pointer in instant)

Secondary menus

Record video/audio



Select pen/highlighter color and line thickness





wheel breakdown

Record Wheel

Record Wheel

This wheel is accessed by pressing the record button on any of the eBeam wheels.

